EMERGENCY CHECKLIST

C-182P LN-BLU

BODØ FALLSKJERMKLUBB

REV. 31.12.2014

Bodø Fallskjermklubb

Rev. 31.12.2014

AIRSPEEDS

Engine failure after take off	Flaps UP	80 MPH
_	Flaps Down	75 MPH
Landing without engine power	Flaps UP	80 MPH
	Flaps Down	75 MPH
Maximum glide	***************************************	80 MPH
Maneuvering speed		
	2000 lbs	

ENGINE & POWER FAILURE

ENGINE POWER LOSS DURING TAKE-OFF

Ignition Switch......OFF
Master Switch....OFF

ENGINE POWER LOSS IMMEDIATELY AFTER DURING TAKE-OFF

Select proper landing area

If time permits:

Mixture......IDLE CUT-OFF

ENGINE FAILURE DURING FLIGHT

Carburator Heat.....ON

Select proper landing area

Fuel selector.....BOTH

Mixture.....RICH

Ignition Switch......Both (or START if propeller is stopped)

Primer.....IN and LOCKED

Restart fails.....continue with EMERGENCY LANDING WITHOUT ENGINE POWER

Bodø Fallskjermklubb

Rev. 31.12.2014

FORCED LANDING

EMERGENCY LANDING WITHOUT ENGINE POWER

75 MPH (Flaps DOWN)

Mixture......IDLE CUT-OFF

Fuel Selector.....OFF

Ignition Switch.....OFF

Master Switch.....OFF

Touchdown.....SLIGHTLY TAIL LOW

Brakes.....APPLY HEAVILY

PRECAUTIONARY LANDING WITH ENGINE POWER

Flaps......20°

Selected airfield......FLY OVER, nothing terrain and obstructions

Avionics Power Switch.....OFF

Electrical Equipment.....OFF

Flaps......40° (on final approach)

Master Switch.....OFF

Doors............UNLATCH PRIOR TO TOUCHDOWN

Touchdown.....SLIGHTLY TAIL LOW

Ignition Switch.....OFF

Brakes.....APPLY HEAVILY

DITCHNG

Radio.....TRANSMIT MAY-DAY on frequency, SQUAWK 7700

Heavy Objects.....SECURE OR JETTISON

Light Winds, Heavy Seas – PARALLEL TO SWELLS

Flaps..... 30^{o} - 40^{o}

Power......ESTABLISH 300' pr. min RATE OF DESCENT AT 70 MPH

Note:

If no power is available, approach at 80 MPH with flaps up or

at 70 MPH with flaps down

Cabin Doors......UNLATCH

Touchdown.....LEVEL ATTITUDE AT ESTABLISHED RATE OF

......DESCENT

Face......CUSHION at touchdown with folded coat.

Airplane.....EVACUATE. If necessary open window to

.....equalize pressure.

Life Vests and Raft......INFLATE

Bodø Fallskjermklubb

Rev. 31.12.2014

ELECTRICAL POWER FAILURE

AMMETER SHOWS EXCESSIVE RATE OF CHARGE(full scale deflection)

Alternator......OFF
Alternator Circuit Breaker....PULL
Non- Essential Equipment....OFF

Flight.....TERMINATE AS SOON AS PRACTICAL

LOW -VOLTAGE LIGHT ON DURING FLIGHT (Ammeter imdicates discharge)

Avionics Power Switches.....OFF

Alternator Circuit Breaker.....OFF

Master Switch.....OFF(Both sides)

Master SwitchON

Low-Voltage light.....CHECK OFF

Avionics Power Switches.....ON(One by one)

If Low- Voltage Light illuminates again:

Alternator.....OFF

Non- Essential Equipment.....OFF

Flight.....TERMINATE AS SOON AS PRACTICAL

FIRE

FIRE DURING START ON GROUND

flames into the engine

If engine starts: Power......1700 RPM

Engine.....SHUTDOWN and inspect for damage

If engine fails to start:

Throttle.....FULL OPEN

Mixture.....IDLE CUT-OFF

Cranking.....CONTINUE

Fire Extinguisher.....OBTAIN

Engine.....SECURE

- Master Switch.....**OFF**

- Ignition Switch......OFF - Fuel Selector.....OFF

Fire.....EXTINGUISH

Bodø Fallskjermklubb

Rev. 31.12.2014

FIRE (Continued)

ENGINE FIRE IN FLIGHT

Mixture......IDLE CUT-OFF

Cabin Heat and Air.....OFF (except overhead vents)

Airspeed......100 MPH, faster if necessary to extinguish fire

Proceed with EMERGENCY LANDING WITHOUT ENGINE POWER

ELECTRICAL FIRE IN FLIGHT

If fire appears out, and electrical power is necessary for continued flight:

Master Switch.....ON

Radio Switches......OFF Avionics

Power Switch.....ON

Radio/Elec. Equipment......ON, one at a time, with delay after each until short

.....circuit is localized

Vents/Cabin Air/Heat......OPEN, when it is ascertained that the fire is extinguished

CABIN FIRE

Vents/Cabin Air/Heat.....**OFF**

Land the airplane as soon as possible to inspect for damage

WING FIRE

Navigation Light Switch......OFF

Pitot Heat Switch.....OFF

Perform a sideslip to keep the flames away from the fuel tank and cabin.

Land as soon as possible using flaps only as required for final approach and touchdown.

WARNING

AFTER DISCHARGING AN EXTINGUISHER WITHIN A CLOSED CABIN, VENTILATE THE CABIN