

Welcome to AVIATION fueling

Read and follow these instructions



Use Credit cards with chip:
Insert your card in the reader with the chip contacts facing up.

Please follow the message flow as prompted in the display.

Leave your card in the reader, until you are prompted to remove it.

You are now prompted to key in your 4 digit pin code followed by the Godkend/accept key (Green key).




Pin code keyboard



Use Shell Aviation cards and Statoil Card.
Insert your card in the reader with the card front (Logos numbers and names) facing up.
Please follow the message flow as prompted in the display.
Remove the card immediately, use a constant speed when you remove it, not to slow. Some cards request pin code, 4 digit pin code followed by the Godkend/accept key (Green key).

Request a receipt

Use the "Receipt" key around the the display and choose your receipt in the same way



After pin code has been entered the following process will take control in Denmark:

1. Choose destination:
2. Aircraft type:




3. Fuel type:



4. Confirm fuel type:



5. Choose pump (if needed)
6. Pump ready



Language in display



Choose language use the "Language" Key around the display.

Credit cards Authorization

When you use credit cards you will be prompted to enter the maximum volume you will fuel.

This enable the system to get preauthorization for your benefit.

